


"S" Curve

Reference Point @ "C"



"S" Curve Measurements

Page 2

<u>Distance up reference line (ft-in)</u>	<u>Distance from Reference line</u>
A 1-8	6-8 L
B 0-9	3-9 L
C 0-0	0-0
D 0-0	4-0 R
E 0-0	8-5 R
F 2-10	11-3 R
G 7-8	11-10 R
H 11-3	9-11 R
I 13-1	8-6 R
J 16-0	4-11 R
K 19-2	1-11 R
L 24-5	0-8 R
M 27-10	2-11 R
N 26-8	7-9 R
O 24-6	10-4 R
P 27-2	13-3 R
Q 31-0	9-3 R
R 32-2	5-1 R
S 31-11	1-2 R
T 30-4	2-11 L
U 27-0	5-7 L
V 22-6	5-0 L
W 18-5	2-8 L
X 14-8	1-1 L
Y 10-3	2-0 R
Z 7-1	3-11 R
A' 6-8	0-10L
B' 7-7	4-10L