


NO-NAME, LARGE COURSE

50 CONES

73'x35'

Measurements By:

R. Cofer



MEASUREMENTS FOR "NO-NAME", LARGE COURSE

I. Start by measuring a base line of 31'10".

A. At the following locations along the tape make a mark or put a nail as indicated below:

(1) 0' MARK	(2) 7-1/2" MARK	(3) 1' MARK	(4) 1'6" MARK
(5) 3'6" NAIL	(6) 5'10-1/2" MARK	(7) 6' MARK	(8) 6'4-1/2" MARK
(9) 7' MARK	(10) 8'3" NAIL	(11) 10'5-1/2" NAIL	
(12) 12'8" NAIL	(13) 14'10-1/2" NAIL	(14) 17'9" NAIL	
(15) 19'6" NAIL	(16) 21'11" NAIL	(17) 24'4" NAIL	
(18) 30'10" NAIL	(19) 31'1" MARK	(20) 31'4" MARK	
(21) 31'7" MARK	(22) 31'10" MARK		

NOTE: All of the following measurements MUST be at 90 degree angles to the above measurements.

B. At the 0' mark, measure 41'2" to the right and put a nail.

C. At the 7-1/2" mark, measure 30'10" to the right and put a nail.

D. At the 1' mark, measure 21'3" to the right and put a nail.

E. At the 1'6" mark, measure 10'8" to the right and put a nail.

F. At the 3'6" nail, measure 3' and 6' to the right PLUS 4' and 8' to the left and put nails.

G. At the 5'10-1/2" mark, measure 10'8" to the right PLUS 8' to the left and put nails.

H. At the 6' mark, measure 21'3" to the right and put a nail.

I. At the 6'4-1/2" mark, measure 30'10" to the right and put a nail.

J. At the 7' mark, measure 41'2" to the right and put a nail.

K. At the 8'3" nail, measure 3' and 6' to the right PLUS 8' to the left and put nails.

L. At the 10'5-1/2" nail, measure 8' to the left and put a nail.

M. At the 12'8" nail, measure 8' to the left and put a nail.

N. At the 14'10-1/2" nail, measure 8' to the left and put a nail.

O. At the 17'9" nail, measure 8' , 11'1" , and 15' to the left and put nails.

P. At the 19'6" and the 21'11" nail, no further measurements are needed.

Q. At the 24'4" nail, measure 4' , 8' , 11'1" and 15' and put nails.

R. At the 30'10" nail, no further measurement is needed.

S. At the 31'1" mark, measure 4' to the left and put a nail.

CONTINUED

MEASUREMENTS FOR THE "NO-NAME", LARGE COURSE
CONTINUED

T. At the 31'4" mark, measure 8' to the left and put a nail.


U. At the 31'7" mark, measure 11'6" to the left and put a nail.

V. At the 31'10" mark, measure 15' to the left and put a nail.

II. MEASUREMENTS FOR THE BULB

A. With TWO measuring tapes, measure 20' across from the PRIMARY mark and the SECONDARY mark for the bulb.

EXAMPLE



B. Find where the 9'6" point on each tape intersect each other and mark this spot as the center of the bulb.

C. Measure 4' from the primary mark and 9'6" from the center of the bulb using both tapes. Put a nail where both measurements intersect. Continue like this until the bulb connects with the secondary mark.

III. ALL MEASUREMENTS ARE FOR CENTER OF CONE TO CENTER OF CONE